

**FOURTH CHARACTER DESIGNATOR:**

**"D" = Shipments up to March 2006**

With effect from shipments in April 2006,

The fourth character designates the type of PLL used:

**"A" = NOVA Receiver**

**"B" = NPC Receiver with 16.8MHz Crystal**

**"C" = ALL CRYSTAL Receiver**

**"E" = Narrowband Receiver**

**"F" = NPC Receiver with 11.25MHz Crystal**

**"G" = NPC Receiver with microchip MCU (BR502) (Archive)**

**"H" = NJRC Receivers**

**"J" = NJRC Narrowband Receivers**

**"X" = Not used**

**FIFTH CHARACTER DESIGNATOR:**

The fifth character designates the year the product was shipped from the manufacturing facility but cannot be vowels "I" and "O":

**"A" = 2000, "B" = 2001, "C" = 2002, "D" = 2003, "E" = 2004, "F" = 2005, "G" = 2006, "H" = 2007,**

**"J" = 2008, "K" = 2009, "L" = 2010, "M" = 2011, "N" = 2012, "P" = 2013, "Q" = 2014**

**SIXTH CHARACTER DESIGNATOR:**

The sixth character designates the month the product was shipped from the manufacturing facility:

**"A or B" = January, "C or D" = February, "E or F" = March, "G or H" = April, "J or K" = May, "L or M" = June, "N or P" = July, "Q or R" = August, "S or T" = September, "U or V" = October, "W or X" = November and "Y or Z" = December**

**SEVENTH through TENTH CHARACTER DESIGNATOR:**

The last four (4) characters of the serial number are sequential numbers but CANNOT contain "Y", "0", "1", or any vowels ("A", "E", "I", "O", "U").

**Serial Number Example: 51PACJ8888**

Bravo 501 Pocsag (Product Code "51P") with NOVA receiver (PLL code "A"), Factory Ship Year is 2002 (Year Code "C"), Factory Ship Month is first half month of May (Month Code "J"), unit sequence code (8888).